WF series flexible measuring current transformers ...

Flexible measuring current transformers WF170, WF250, WF500, WF800, WF1200

BFNDFR

Consisting of an RCC420 signal converter and a W...F measuring current transformer



WF... series measuring current transformers

Device features

- Flexible measuring current transformer in different lengths
- Allows quick and easy installation in hard to reach areas
- · Easy retrofitting into existing installations
- Can be installed without the need to disconnect the conductors
- CT connection monitoring W...F
- For RCMS460 / 490 series residual current monitoring systems
- Analogue output (U, I) for external measuring devices
- RCC420 with push-wire terminals (two terminals per connection)

Approvals and certifications



Product description

Flexible WF... series measuring current transformers are highly sensitive measuring current transformers, which measure AC currents in conjunction with a RCMS460 / 490 series residual current monitor and convert them into an evaluable measuring signal.

They consist of one flexible W...F measuring current transformer and one RCC420 signal converter. Connection to the respective evaluator is via a two-wire cable.

Application

- Residual, fault and nominal current monitoring of loads and systems which cannot be switched off
- EMC monitoring of TN-S systems for "stray currents" and additional N-PE connections in the central earthing point (CEP)
- Monitoring of PE and equipotential bonding conductors to ensure they are free of current

Installation instructions

- Make sure to pass all live conductors through the measuring current transformer
- Arrange the conductors so that they pass centrically at right angle through the opening
- Do not place the measuring current transformer close to strong magnetic fields

Wiring diagram

Connection to the respective RCMS460 / 490 series residual current evaluator



- Power On LED "ON": lights up when voltage is available and when the device is in operation
- 2 Alarm LED "ERR": Lights in the event of a short-circuit and interruption of the W...F
- Up to software version D233 V 2.21
 Switch off CT monitoring
 Software version D233 V 2.31 and higher
 Set the CT type to "flex"

Technical data Electrical safety Standard: RCC420 IEC 61010-2-030: 2004-05-01 Pollution degree Rated insulation voltage Standard: WF... IEC 1010-1 and IEC 1010-2-032 CAT III Pollution degree 1000 Vrms or DC Rated insulation voltage (CAT III) Supply voltage Supply voltage Us see ordering information Power consumption \leq 3 VA **Measuring circuit** 100 mA...20 A Measuring range Rated transformation ratio K_N (U - I): 100 mV / A, K_N (k - I): 1.67 mA / A Rated burden (signal outputk, I) Rated frequency 42...2000 Hz Rated continuous thermal current Icth Rated short-time thermal current Ith 60 kA / 1 s Rated dynamic current Idyn 150 kA / 40 ms EMC Operating temperature - 25 °C...+ 55 °C Climatic class acc. to IEC 60721 Stationary use (IEC 60721-3-3) 3K5 (except condensation and formation of ice) Transport (IEC 60721-3-2) 2K3 (except condensation and formation of ice) Long-time storage (IEC 60721-3-1) 1K4 (except condensation and formation of ice) Classification of mechanical conditions IEC 60721 Stationary use (IEC 60721-3-3) Transport (IEC 60721-3-2) Long-time storage (IEC 60721-3-1) **Connection RCC420** push-wire terminals Connection type 0.2...2.5 mm² / AWG 24-14 Connection properties rigid Flexible without ferrule 0.2...2.5 mm² / AWG 24-14 Flexible with ferrule 0.2...1.5 mm² / AWG 24-16 Stripping length 10 mm Opening force Test opening, diameter 2.1 mm Connection measuring current transformer W...F PS / 2 plug Cable length W...F Cable lengths RCMS-RCC420... Single wire $\geq 0.75 \text{ mm}^2$ 0...1 m 0...10 m Single wire twisted $\ge 0.75 \text{ mm}^2$ Shielded cable $\geq 0.5 \text{ mm}^2$ 0...40 m Recommended cable (shielded, shield to terminal I, not connected to earth) J-Y(ST)Y min. 2 x 0.8 **Other** Operating mode continuous operation Mounting any position Degree of protection, internal components / terminal (DIN EN 60529) IP 30 / IP 20 Enclosure material RCC420 polycarbonate Flammability class UL94V-0 DIN rail mounting acc. to IEC 60715 Screw mounting 2 x M4 with mounting clip Operating manual TBP409020 RCC $420 \le 160 \text{ g}$ WF500 \leq 200 g Weight

Note: The measuring current transformer is adapted to the asso	oc
ated signal converter RCC420.	

WF170 \leq 160 g

WF250 \leq 180 g

Ordering information					
Туре	Length A measuring current trans- former	Supply voltage Us*	Art. No.		
WF170-1	170 mm	DC 9.694 V / AC 42460 Hz 1672 V	B 7808 0201		
WF170-2	170 mm	DC 70300 V / AC 42460 Hz 70300 V	B 7808 0202		
WF250-1	250 mm	DC 9.694 V / AC 42460 Hz 1672 V	B 7808 0203		
WF250-2	250 mm	DC 70300 V / AC 42460 Hz 70300 V	B 7808 0204		
WF500-1	500 mm	DC 9.694 V / AC 42460 Hz 1672 V	B 7808 0205		
WF500-2	500 mm	DC 70300 V / AC 42460 Hz 70300 V	B 7808 0206		
WF800-1	800 mm	DC 9.694 V / AC 42460 Hz 1672 V	B 7808 0207		
WF800-2	800 mm	DC 70300 V / AC 42460 Hz 70300 V	B 7808 0208		
WF1200-1	1200 mm	DC 9.694 V / AC 42460 Hz 1672 V	B 7808 0209		
WF1200-2	1200 mm	DC 70300 V / AC 42460 Hz 70300 V	B 7808 0210		
* Absolute values					

3

250 V

68 Ω

1 kA

3M4

2M2 1M3

50 N

2 m

WF800 \leq 230 g

 $WF1200 \le 310 \text{ g}$

Accessories	
Туре	Art. No.
Mounting clip for XM420 enclosure (RCC420) (one unit required per device)	B 9806 0008

Dimension diagram XM420

Dimensions in mm Open the front plate cover in direction of arrow!



Screw mounting

Note: The upper mounting clip must be ordered separately (see "Accessories")



Dimension diagram W...F series measuring current transformers

A = For details about the length of the measuring current transformer refer to ordering information



Locking connector measuring current transformer W500F...W1200F Keep the locking connector clean



Locking connector measuring current transformer W170F...W250F